

amzchef

1800W

INDUCTION

1500W

INDUCTION

 Please don't touch the hot surface after cooking!



Child Lock
Verrouillage

ON/OFF control
Marche / Arrêt

Timer
Minuterie

Power and timer controls
Puissance et Minuterie commandes

Upper / Lower heating zone selection
Selection / zone de chauffage